

## The serial port of MSP doesn't work. What's wrong?

- 2018-02-09 - HiOS

Please make sure that you use the proper cable. **MSP** needs a serial cable with an **RJ45 connector** (with respective pin assignment).

Note that RSP uses the standard Hirschmann serial cable with RJ11 connector.

Serial configuration: 9.6 kbd, 8N1.