


How to add an Industrial HiVision license

- 2022-01-10 - Industrial HiVision

This howto describes the procedure to add a license in Industrial HiVision (IHV).

Prerequisites: Installed Industrial HiVision, eMail with IHV license code

Open IHV Preferences




Start Industrial HiVision and open the '**Prefrences**' dialog (Configuration - Preferences)

eMail including License Key




Copy the license code from the received eMail.

License Dialog - New Entry



1. Click '**New**' to add an entry
2. Paste the license key from the received license eMail
3. Close the pop-up window with '**Ok**'

License Dialog - check for valid license



Valid licenses are shown without background color, red entries are expired.
Below you can see the total number and remaining licenses.

Event log message



The screenshot shows a window titled "Unacknowledged Events" with a table of event log entries. The table has columns for ID, Ack., Type, Category, Time, User, Source, Component, and Message. Three entries are visible, all with the "Ack." checkbox unchecked. The first entry (ID 66) is a "User Intervention" event. The second (ID 68) and third (ID 67) are "License" events.

| ID | Ack. | Type | Category | Time | User | Source | Component | Message |
|----|--------------------------|-------------------|-------------------|---------------------|------|-----------------------------|-----------|---------------------------------|
| 66 | <input type="checkbox"/> | User Intervention | User Intervention | 2014-03-17 16:03:57 | | Industrial HiVision | | Preferences Modified by User |
| 68 | <input type="checkbox"/> | License | License | 2014-03-17 16:03:57 | | Industrial HiVision Service | | Industrial HiVision is licensed |
| 67 | <input type="checkbox"/> | License | License | 2014-03-17 16:03:57 | | Industrial HiVision Service | | Number of Licenses: 3300 |

After closing the preferences dialog you can see an event log with the new number of licenses.