

Base de conocimiento > Products > Classic Firewalls > How to set up a VPN connection between EAGLE20 and the LANCOM Advanced VPN Client (NCP client) ?

How to set up a VPN connection between EAGLE20 and the LANCOM Advanced VPN Client (NCP client)?

- 2024-03-08 - Classic Firewalls


This lesson describes how to configure a VPN using Hirschmann EAGLE20 and the LANCOM Advanced VPN Client.

Used software versions:

EAGLE20 firmware v5.2.00

Lancom Advanced VPN Client v2.30 Build 146

Network Plan




Install and start LANCOM Advanced VPN Client



The LANCOM Client with a 30 day evaluation period can be downloaded from http://www.lancom-systems.de

Import Certificates


After installation start the LANCOM VPN Client.



Copy the PEM export of the CA (in our example L3CA.pem) and the PKCS#12 export of the LANCOM Client certificate (in our example LANCOM_client.p12) in the CaCerts directory: C:\Program Files (x86)\LANCOM\Advanced VPN Client\CaCerts

Note: The file extension of the CA export must be .pem otherwise the LANCOM Client will not find the CA.

CA Certificates



To verify if the LANCOM Client could load the CA, select Connection -> Certificates -> Display CA Certificates from the menu.


The distinguished name of the CA should be displayed, marked with a green checkmark. Click Close.

Certificates Configuration



Select Configuration -> Certificates from the menu.

Certificate Selection




Highlight the Standard certificate configuration and click Edit.

Set the PKCS#12 Filename in our example C:\Program Files (x86)\LANCOM\Advanced VPN Client\CaCerts\LANCOM_Client.p12.

Click OK.

Close the Certificates configuration window.

Creating a new profile



- 1. Select from the menu Configuration -> Profiles
- 2. Click Add / Import to create a new profile
- 3. Select Link to Corporate Network Using IPsec
- 4. Click Next

Profile Name



Enter a Profile Name


Click Next

Communication Medium



Select LAN (over IP) as communication media Click Next

VPN Gateway Parameters



Enter the **Gateway** to which the connection should be established. Could be an IP address or DynDNS name.


IPsec Configuration



Set the Exchange Mode to main mode (IKEv1)
Set PFS Group to DH-Group 2 (1024 Bit)

Click **Next**

Local Identity (IKE)




Delete the pre-shared keys

Set the Type to **ASN1 Distinguished Name**

Using the test certificates, copy the DN


/C=DE/ST=BW/L=NT/O=HAC/CN=LANCOMClient in the ID field Click Next

IPsec Configuration - IP Addresses




Set the IP Address Assignment to Manual IP Address.

IPsec Configuration - Split Tunneling




Define the remote IP network to be reached through the IPsec tunnel. In our example 192.168.10.0/24. Click Finish.

Profile Window



The new profile is created and displayed in the **Profile** window Highlight the profile and click **Edit.**


Profile Settings



Highlight IPsec General Settings in the left pane.


Click **Policy Editor**

IKE Policy Settings



Highlight **RSA Signature** in the IKE Policy

Click **Edit**




Set Encryption to AES 128 Bit.

Set Hash to SHA.


Set DH Group to DH-Group 2 (1024 Bit)

Note: The specified encryption and hash algorithms must correspond to the settings in the EAGLE

IPsec Policy Settings



Highlight the entry **ESP-AES128-MD5** in the **IPsec Policy** tree. Click **Edit.**



Change the Name to ESP-AES128-SHA.


Set Encryption to AES-128 Bit.

Set Authentication to SHA.

Click OK.


Close the IPsec Configuration window.

Select IKE and IPsec Policy



Set the IKE Policy to **RSA Signature**Set the IPsec Policy to **ESP-AES 128-SHA**

Policy Lifetimes




Click the button **Policy Lifetimes.**

Change the **IPsec Policy Life Time** to **1 hour.**

Click OK.

Profile Settings - Identities



Navigate to **Identities.**

Select Standard certificate configuration.

Click OK.


Click **Ok** to close the **Profile** Window.

LANCOM Client configured



The LANCOM Client configuration is finished

EAGLE20 Configuration



- 1. Switch the EAGLE20 into router mode
- 2. Set IP addresses of internal and external interface accordingly.

In our example: Internal Interface 192.168.10.1/24; External Interface: 172.16.1.1/24

Starting from a default configuration the CLI commands to configure the device via serial connection are:


(Hirschmann Eagle) #network mode router

(Hirschmann Eagle) #network router param int ip-address 192.168.10.1

(Hirschmann Eagle) #network router param ext ip-address 172.16.1.1


3. Login to the webinterface of the EAGLE20 from the internal network (192.168.10.0/24)

VPN Configuration Web Interface



- 1. Navigate in the web interface tree to **Virtual Private Network -> Connections**.
- 2. Create a new Entry.
- 3. Highlight the new entry and click **Edit**

VPN - Basic Settings



Name the VPN connection.

Change to next tab Authentication.

VPN - Authentication - Import Certificate




- 1. Select x509rsa.
- 2. Click on Load PKCS#12
- 3. Specify location of the AFF certificate and password. The password of the test certificates is 'test'.
- 4. Click Copy from PC


Identities

Change the **Remote Type** to asn1dn.

Copy the distinguished name of the LANCOM Client certificate in the field **Remote ID.**In our example /C=DE/ST=BW/L=NT/O=HAC/CN=LANCOMClient
Change to the next tab **Certificates.**

VPN - Certificates






After successfully imported the certificate in the previous step you'll get the content of the PKCS#12 file displayed here.

Change to the next tab IKE (Key Exchange)

VPN - IKE (Key Exchange)



- 1. Set **Startup as** to **responder.**
- 2. The **Lifetime** should correspond to the LANCOM Client settings (8 hours) but is entered here in seconds.
- 3. Set the encryption **algorithms** accordingly in our example:

Key Agreement: modp1024


Hash: **sha1**

Integrity: **hmacsha1**Encryption: **aes128**

4. Set the **Local IP Address** to **172.16.1.1**

5. Set the **Remote IP Address** to **172.16.1.143** Change to the next tab **IPsec (Data Exchange)**

VPN - IPsec (Data Exchange)



The **Lifetime** in seconds should correspond with the settings of the LANCOM Client (1 hour) Set the encryption **algorithms** accordingly.


In our example:

Key Agreement: modp1024

Integrity: **hmacsha1**Encryption: **aes128**

Change to the next tab **IP Networks**

VPN - IP Networks



1. Create a new Entry

Enter the following values:

Source Address: 192.168.10.0/24 (internal network EAGLE20)


Destination Address: 172.16.106.201/32 (virtual Address of LANCOM Client)

Policy: **require** (traffic is not routed if tunnel is down)

2. Click **Set** to write the changes on all tabs in the device

Click **Back**

Activate VPN Connection



Activate the created VPN connection.


Click **Set**

Initialize Tunnel Setup



- 1. Move the Connection slide to the right to initialize the tunnel setup. You will get prompted to enter the certificate's pin. In our example 'test'
- 2. The connection should be established successfully.

LANCOM Advanced VPN Client - Log



Select Log -> Logbook

EAGLE20 - Logfile



In the EAGLE20 web interface navigate to **Diagnostics -> Events -> Event Log.**Make sure that **all** events or at least the **category IPsec** and **VPN VPN** is checked, then click **Show Events**

EAGLE20 Event Log

