


Industrial Hivision Scheduler - Save Device Configurations

John M - 2019-12-23 - Industrial HiVision

This guide is designed to walk through the steps to configure Hirschmann Industrial HiVision to enable the scheduled remote backup of Configurations of the Hirschmann devices in a project.


1. Once Hivision is running go to the Device tab and highlight the devices that need the configurations saved, right click on one of the highlighted devices and select Save Device Configuration.




The screenshot shows the HiVision software interface. The 'Device' tab is selected, displaying a table of network devices. The table columns include Type, Status, Name, IP Address, MAC Address, Product, Chassis, Serial No., System Name, Location, Contact, Firmware Version, Chassis Name, Configuration Sig., and PSM up to. Several devices are highlighted in blue, indicating they are selected for configuration saving.

Type	Status	Name	IP Address	MAC Address	Product	Chassis	Serial No.	System Name	Location	Contact	Firmware Version	Chassis Name	Configuration Sig.	PSM up to
Router	OK	192.168.0.2	192.168.0.2	EC-E5-55-66-98-69	EAGLE 20/20	EAGLE-20-940099...	94205899900030...	EAGLE-ECE55566...	Hirschmann EAGLE	Hirschmann Auto...	940055-03.0.00		139f054380c3e38...	
Router	OK	192.168.0.9	192.168.0.9		Ping Device									
Router	OK	192.168.0.11	192.168.0.11		Ping Device									
Router	OK	192.168.0.75	192.168.0.75	EC-E5-55-FF-ED-08	BAT540-ALL	RSP-E37-740-407	94208499901070...	RSP-E37-740-407	Hirschmann SSP	Hirschmann Auto...	940035-07.0.04		FX00ED57AA657	
Router	OK	192.168.0.76	192.168.0.76	EC-E5-55-FF-ED-08	BAT540-ALL	BAT-#	94207099904150...	BAT-#_master	www.hirschmann...					
Router	OK	192.168.0.77	192.168.0.77	EC-E5-55-FF-D1-4B	BAT540-ALL	BAT-#	94207099900000...	BAT-#_WALIMAS...	www.hirschmann...					
Router	OK	192.168.0.78	192.168.0.78	EC-E5-55-FF-D1-4B	BAT540-ALL	BAT-#	94207099903040...	BAT-#_B...	www.hirschmann...					
Router	OK	192.168.0.160	192.168.0.160	EC-E5-55-36-70-88	R520	R520-160042	94343400525580...	Row 1 Lin	Hirschmann Rals...	Hirschmann Auto...	13E-59.0.07		16 88 4d 4d	
Router	OK	192.168.1.1	192.168.1.1		Ping Device									
Router	OK	192.168.1.57	192.168.1.57	04FD3122-88-29	BAT540-ALL	BAT8674R	94343400200000...	Office switch	Home office	Hirschmann Auto...	13E-59.0.07		7a 69 36 5c	
Router	OK	192.168.1.57	192.168.1.57	04FD3122-88-29	BAT540-ALL	BAT8674R	94343400200000...	BAT8674R_F42-300		www.hirschmann...	0.14-ALPHA			


2. Browse to the location the configurations need to be saved to, set the start time (making sure to leave enough time to finish the schedule before it starts), and frequency the configurations need to be saved. Then make sure all of the other settings are selected properly and click OK.




3. To verify it has been scheduled click on Configuration in the taskbar and select Scheduler, the task tab will show the devices and the task to be performed



4. The schedules tab will show the schedule to perform the tasks.



5. To verify the tasks have been completed click on the results tab.



6. Finally verify the configurations have been saved to the correct location.

